

# 1 BOSCH EDC17CP20 IROM TC1796 EGPT VAG

## 1.1 PLUGIN 1159: NEW TRASDATA


## 1.2 CONNECTIONS

### 1.2.1 EGPT CONNECTION

The following cables must be used to communicate correctly with the ECU:



WIRE COLOUR		DESCRIPTION
	Red	+12 V
	Black	GND
	Green	CAN L
	White	CAN H
	Grey	GPT0
	Blue	GPT1



For further information on the use of the F34NTA22-S2/S3/S5/S6 cables, see the [article](#).

