

1 CONTINENTAL ATK-EM-EU6 SPC564A80 JTAG VOLVO TRUCK

1.1 PLUGIN 1822 : NEW TRASDATA








1.2 CONNECTIONS

1.2.1 LOOSE WIRES CONNECTION - ECU READING AND WRITING




ATTENTION

After making all the connections, connect a stabilized power supply to the New Trasdata and make sure that the POWER LED (red) is on.

To communicate correctly with the control unit, it is necessary to use the F32GN037C/D cable.



WIRE COLOUR		DESCRIPTION
	Red	+12 V
	Black	GND



It is necessary to use the cable F34NTF53 for reading and writing.



PIN	WIRE COLOUR
16	BLUE
18	GREY
19	WHITE
20	BLACK
21	BROWN
22	RED
24	YELLOW



ATTENTION

Connect the wires on the pads avoiding any short circuits.

